

PRELIMINARY

OPERATING INSTRUCTIONS EX38A REV. 0

Variable Reluctance Speed Sensor for Use in Explosive Atmospheres EX38A GREEN L

GREEN LINE
INDUSTRIAL SPEED SENSORS

Pr	od	luct	ID
----	----	------	----

Type #	Product #	Drawing #
EX38A	385Z-05566	113.703 Rev.1

General

Function

The EX38A series variable reluctance (VR) speed sensors consist of an iron core, an inductive coil, and a permanent magnet. A ferrous pole wheel passing the sensor face changes the magnetic field strength, resulting in an AC voltage being induced in the coil. The frequency of the output signal is proportional to the speed of the moving target. The amplitude of the signal depends on speed, air gap, geometry of target, magnetic properties of target material, and the electrical load. VR sensors, also known as passive or electromagnetic sensors, do not require an external supply.

Usage in an explosion risk

Certification pending. Details will follow after finished certification.

environment

II 3 G EEx nA IIB T3 (pending)

Technical data

Coil properties

- Inductance @ 1 kHz: 170 mH ± 10%
- Resistance: 850 Ohm ± 10%
- · Magnet polarity: north pole towards front face
- Pole piece: diameter 2.7 mm

Polarity


Signal output

Marking

Upon approach of ferrous metal, the signal pin is positive with respect to GND. The signal frequency is proportional to the target speed.

The signal amplitude shown in the figure is valid for a load of 100 kOhm, and is affected by air gap, target geometry and material. It is also proportional to the

linear speed of the teeth.



Frequency range	Up to 20 kHz, lower limit depending on application	
Housing	3/8"-24 UNF-2A, tightening torque: max. 10 Nm	
Connection	Connector: M12x1 thread, 4 pins, black	
Protection	Sensor head: IP68 Connector: IP67	
Insulation	Housing and electronics galvanically isolated (Test: 500 V, 50 Hz for 1 minute)	
Pole wheel	Prerequisite: Toothed wheel of a ferrous material (e.g. Steel 1.0036). Optimal performance with	

www.jaquet.com Tel.: +41 61 306 88 22 Page 1/3



IN CHARGE OF SPEED

OPERATING INSTRUCTIONS EX38A REV. 0

	 Involute gear Tooth width > 10 mm Side offset < 0.2 mm Eccentricity < 0.2 mm 	
Air gap between sensor and pole wheel	Depending on lowest circumferential speed which has to be detected, on trigger level and ex safety parameters. See figure and ex information.	
Electromagnetic compatibility (EMC)	Please contact Jaquet for further details.	
Vibration & shock immunity	Jaquet Greenline sensors are approved for rough environments. Please contact Jaquet for further details.	
Operating temperature	-40℃125℃	
Further Information		
Safety	All mechanical installations must be carried out by an expert. General safety requirements have to be met.	
Installation	The sensor has to be aligned to the pole wheel according to the sensor drawing independent of its rotational orientation. Deviations in positioning may affect the performance and decrease the noise immunity of the sensor. During installation, the smallest possible pole wheel to sensor gap should be set. The gap should however be set to prevent the face of the sensor ever touching the pole wheel. A sensor should be mounted with the middle of the face side over the middle of the pole wheel. Dependent upon the wheel width, a certain degree of axial movement is permissible. However, the middle of the sensor must be at minimum in a distance of 3 mm from the edge of the pole wheel under all operating conditions. A solid and vibration free mounting of the sensor is important. Eventual sensor vibration relative to the pole wheel can induce additional output pulses. The sensors are insensitive to oil, grease etc. and can be installed in arduous conditions.	
Maintenance	Product cannot be repaired.	
Transport	Product must be handled with care to prevent damage of the front face.	
Storage	Product must be stored in dry conditions. The storage temperature corresponds to the operation temperature.	
Disposal	Product must be disposed of properly, it must not be disposed as domestic waste.	

info@jaquet.com Tel.: +41 61 306 88 22 Page 2/3 www.jaquet.com



PRELIMINARY

OPERATING INSTRUCTIONS EX38A REV. 0

