

Quick Start Guide

Getting to Know Your EL-SIE Logger



For full information about your data logger visit www.lascarelectronics.com and navigate to the product page of your logger. The data sheet is in the Resources section.



Install the Batteries

The unit is powered by two user replaceable non-rechargeable AAA alkaline batteries. Other battery types are not recommended.

Loosen the screws and remove the end cap, then fit the batteries in the orientation shown on the label. Replace the end cap and tighten the screws carefully until secure.

Connect to your PC or Mac














No software is needed! To configure, view and analyse the data from your EL-SIE, simply follow these steps:

1. Connect the logger to your computer using the USB cable supplied
2. Open your web browser and into the address bar type <http://EasyLog.local>
3. The EL-SIE home page will load – save it to your Favourites or Bookmarks
4. Follow the on-screen instructions to configure and start logging
5. Disconnect the logger and position it where you want to take readings





Once the logger is running you can plug it back into your computer and, without having to stop it logging, view the data recorded so far. Just select <http://EasyLog.local> from your Favourites and click on View/Save Data.



EasyLog Cloud Data Storage

| | | | | | |
|---|-----------------------------|---|---|------------------|---|
|  | | Triggered start logging and will start logging as soon as the specified limit (either temperature, humidity or pressure) is reached |  | Cumulative Alarm | A cumulative alarm is active on the channel currently being displayed |
|  | Low Battery Warning | The batteries are low and should be changed when possible |  | High Alarm | A high alarm is active on the channel currently being displayed |
|  | Memory Full Warning | The memory is full and logging has stopped |  | Low Alarm | A low alarm is active on the channel currently being displayed |
|  | Memory 90% Warning | The memory is 90% full, and data should be downloaded when possible |  | Held High Alarm | A high alarm is being held on the channel currently being displayed |
|  | Calibration Pending Warning | The calibration will expire in < 30 days on the date shown (can be DD/MM/YYYY or MM/DD/YYYY) |  | Held Low Alarm | A low alarm is being held on the channel currently being displayed |
|  | Calibration Expired Warning | The calibration has expired on the date shown (can be DD/MM/YYYY or MM/DD/YYYY) |  | High Pre-alarm | A high pre-alarm is active on the channel currently being displayed |
| | | |  | Low Pre-alarm | A low pre-alarm is active on the channel currently being displayed |

Status LEDs and Sounder

| LEDs | Sounder | Status | LEDs | Sounder | Status |
|---|---------|--|---|---------|---|
|  Flashing | Off | Logger in operation, no alarms or warnings |  Flashing | Active | Alarm / Memory Full / Calibration Expired |
|  Flashing | Off | Logger primed but not yet logging / Pre-alarm / Memory 90% Full / Calibration Pending (check display for specific warning) |  Slow Flash | Off | Battery Low |

Button Functions

| Screen | Button | Press | Function | Event Recorded |
|---------------------------|--------|-------|--|-------------------|
| USB | n/a | n/a | n/a | n/a |
| Push to Start | Any | Long | Start logging | n/a |
| Triggered Start | n/a | n/a | n/a | n/a |
| Delayed Start | n/a | n/a | n/a | n/a |
| Channel – Current reading | Top | Short | Move to next channel or STOP LOG | n/a |
| | | Long | Clear alarm hold for all channels | Clear Held Alarms |
| | Bottom | Short | Show Min reading for this channel | n/a |
| | | Long | Mute alarm sounder | Mute Alarm |
| Channel – Min reading | Top | Short | Show Min reading for next channel or STOP LOG | n/a |
| | | Long | Reset Max/Min reading for all channels | Clear Max/Min |
| | Bottom | Short | Show Max reading for this channel | n/a |
| | | Long | Mute alarm sounder | Mute Alarm |
| Channel – Max reading | Top | Short | Show Max reading for next channel or STOP LOG | n/a |
| | | Long | Reset Max/Min reading for all channels | Clear Max/Min |
| | Bottom | Short | Show current reading for this channel | n/a |
| | | Long | Mute alarm sounder | Mute Alarm |
| STOP LOG? | Top | Short | Move to Channel 1 (or Warning Screen), also generates an Audit Mark when cycling back through to Channel 1 | Audit Mark |
| | Bottom | Long | Stop logging, returns to Push to Start | n/a |
| Warning Screen | Any | Short | Move to next warning or Channel 1 | n/a |

IMPORTANT SAFETY INFORMATION