

OPERATING INSTRUCTIONS E16AM25 REV. 1

# Variable Reluctance Speed Sensor E16AM25



INDUSTRIAL SPEED SENSORS

### **Product ID**

	Type #	Product #	Drawing #	
	E16AM25	385Z-05573	114.451 Rev.0	
General				
Function	core, an inductive coil, and the sensor face changes th being induced in the coil. T speed of the moving target gap, geometry of target, m	a permanent magnet, ne magnetic field streng The frequency of the ou t. The amplitude of the agnetic properties of ta own as passive or elect	eed sensors consist of an iron A ferrous pole wheel passing gth, resulting in an AC voltage ttput signal is proportional to the signal depends on speed, air arget material, and the electrica romagnetic sensors, do not	
Technical data				
Coil properties	<ul> <li>Inductance @ 1 kHz: 17</li> <li>Resistance: 850 Ohm ±</li> <li>Magnet polarity: north p</li> <li>Pole piece: diameter 2.7</li> </ul>	10% ole towards front face		
Polarity	Upon approach of ferrous	metal, the signal pin is	positive with respect to GND.	
Signal output	The signal frequency is proportional to the target speed. The signal amplitude shown in the figure is valid for a load of 100 kOhm, and is affected by air gap, target geometry and material. It is also proportional to the linear speed of the teeth.			
	Typical output voltage (reference speed 10 m/s, 100 kOhm load)			
	100.00 () 100.00 () 100.00 () 100.00 () () () () () () () () () ()	1.5 2 2.5 Air gap (mm)		
Frequency range	Up to 20 kHz, lower limit depending on application			
Housing	M16x1.5, tightening torque: max. 35 Nm			
Connection	Connector mates with straight plug MS3106A-10SL-4S, 2 pins			
Protection	Sensor head: IP68 Connector: IP67			
Insulation	Housing and electronics galvanically isolated (Test: 500 V, 50 Hz for 1 minute)			
Pole wheel	<ul> <li>Prerequisite: Toothed wheel of a ferrous material (e.g. Steel 1.0036).</li> <li>Optimal performance with <ul> <li>Involute gear</li> <li>Tooth width &gt; 10 mm</li> <li>Side offset &lt; 0.2 mm</li> <li>Eccentricity &lt; 0.2 mm</li> </ul> </li> </ul>			
	<ul> <li>Side offset &lt; 0.2 mm</li> <li>Eccentricity &lt; 0.2 mm</li> </ul>			



## IN CHARGE OF SPEED

### **OPERATING INSTRUCTIONS** E16AM25 REV. 1

pole wheel	trigger level. See figure.	
Electromagnetic compatibility (EMC)	Please contact Jaquet for further details.	
Vibration & shock immunity	Jaquet Greenline sensors are approved for rough environments. Please contact Jaquet for further details.	
Operating temperature	-40°C125°C	
Further Information		
Safety	All mechanical installations must be carried out by an expert. General safety requirements have to be met.	
Installation	The sensor has to be aligned to the pole wheel according to the sensor drawing independent of its rotational orientation. Deviations in positioning may affect the performance and decrease the noise immunity of the sensor. During installation, the smallest possible pole wheel to sensor gap should be set. The gap should however be set to prevent the face of the sensor ever touching the pole wheel. A sensor should be mounted with the middle of the face side over the middle of the pole wheel. Dependent upon the wheel width, a certain degree of axial movement is permissible. However, the middle of the sensor must be at minimum in a distance of 3 mm from the edge of the pole wheel under all operating conditions. A solid and vibration free mounting of the sensor is important. Eventual sensor vibration relative to the pole wheel can induce additional output pulses. The sensors are insensitive to oil, grease etc. and can be installed in arduous conditions.	
Maintenance	Product cannot be repaired.	
Transport	Product must be handled with care to prevent damage of the front face.	
Storage	Product must be stored in dry conditions. The storage temperature corresponds to the operation temperature.	
Disposal	Product must be disposed of properly, it must not be disposed as domestic waste.	





### OPERATING INSTRUCTIONS E16AM25 REV. 1

